

# J&S Technical Information

## Exhaust Pipe Shaper – L3200



### Introduction

To repair pipes that are crushed or bent. This tool can be used to reshape pipes that are flared out as well as bent in.

Range is 1 1/2" – 3 5/8"

