

J&S Technical Information

Oil Filter Remover – L6360



Introduction

Fits small filters found on Japanese cars and allows their removal without endangering the oil pressure sender which is commonly found next to the filter. These tools are sprung loaded to hold them onto the filter before pressure is applied via the 3/8" drive. Cap 2 1/2" - 3 1/8".

